


# QM-800

FVW


PIONEER

## QM-800




## MAIN AMP UNIT



W23-009




PROTECTION UNIT  
AWM - 005




### MOUNTING TEMPLATE



PROTECTION UNIT  
AWM - 003



POWER SUPPLY UNIT  
AWR - 001



Remove the four feet on the bottom plate of the unit.

