


QT-6100



- S1 FWD-REV SELECTOR SW (FWD POSITION)
- S2, S5 REC-PB SELECTOR SW (PB POSITION)
- S3 EQUALIZER SELECTOR SW (7 1/2 IPS POSITION)
- S4 MODE SW (4 CHANNEL POSITION)
- S6 MUTING SW (PLAY POSITION)
- S7 CONTACT OFF SW (PLAY / STOP POSITION)
- S8 PRE SET SW
- S9 PLINGER SW (FWD POSITION)
- S10 MOTOR SW
- S11 SHUT OFF SW
- S12 POWER SW
- S15 OSC. SW.
- RL1 FWD-REV SELECTOR SW (FWD POSITION)
- VR1, 101 PB. EQUALIZER ADJ (FWD POSITION)
- VR2 PB. EQUALIZER ADJ (REV POSITION)
- VR3, 103 PB. LEVEL ADJ (FWD POSITION)
- VR4 PB. LEVEL ADJ (REV POSITION)
- VR5 REC. LEVEL
- VR6, 106 LEVEL METER ADJ
- VR7 REC. LEVEL ADJ
- VR8 LEFT BIAS ADJ
- VR9 RIGHT BIAS ADJ
- VR10 OSC INTENSITY ADJ

FRONT REAR

