

STEREO HEADPHONES

SE-205

OPERATING GUIDE



Leather-like vinyl is used in the construction of head band and ear pads.

 **PIONEER®**

Welcome to the exciting world of Pioneer sound through your purchased stereo headphones, model SE-205!

The SE-205, newly designed for your satisfaction in private listening pleasure, assures you magnificently lifelike performance of stereo music.

Especially, newly adopted fully-enclosed type means that no sound leaks from the ear cups and that no sound disturbs your private listening.

Its application is possible both for stereo music listening and recording monitoring.

FEATURES

- Adoption of large-size dynamic speaker of 70φmm.
- Complete reproduction of dynamic bass, mid range and precise treble.
- Fully-enclosed type effective in blocking off external sound.
- Elegant, modernistic appearance with leatherette pad.
- Comfortable feeling even for lengthy use-without tiredness.




Fig. 1

USING YOUR SE-205

CONNECTION

Your stereo receiver or amplifier has a "PHONES" or "HEADPHONES" jack:

- Set the volume of the receiver or amplifier at a minimum level, then plug the cord of the SE-205 into the "PHONES" jack.
- Be sure the earpiece with the cord is placed on your left ear. If it is reversed, the stereo channels will be reversed, too. For easy identification LEFT and RIGHT are marked on the set.
- Adjust the volume and tone controls of the receiver to your personal preference.




Fig. 2

VARIOUS TYPES OF ADAPTOR AVAILABLE

No "Phones" Jack Equipped (Fig. 3)

If your stereo receiver or amplifier is not equipped with a "PHONES" ("HEADPHONES") jack, use the Pioneer Junction Box JB-21 instead.

Using Two Headphones at the Same Time (Fig. 4)

If you want to use two pairs of headphones to be connected to a single "PHONES" jack at the same time, use a Pioneer JB-25 Adaptor Cord (optional).

Using the SE-205 far from "Earphone" Jack (Fig. 5)

If you want to use the headphones at a spot comparatively far from your television set, radio, cassette tape recorder, use the Pioneer JB-24 with a 3-meter (approx. 9 feet) extension cord. The JB-24 can be connected to two pairs of headphones.

Converting Headphone Plug into Earphone Plug (Fig. 5)

If you want to plug the SE-205 into the earphone jack of a radio, television or cassette tape recorder, use the Pioneer Adaptor Plug JB-26.

HOW TO USE THE JB-21

- Connect the JB-21 to your stereo receiver or amplifier as shown in Fig. 3. For details, see the operating guide furnished with the JB-21.
- Plug the SE-205 cord into the jack of the JB-21, then set the selector switch of the JB-21 to "HEADPHONES."




Fig. 3




Fig. 4

Fig. 5

IMPORTANT

- Never plug the headphones into the receiver if the volume control is turned up. A sudden, strong input signal may damage the headphones.
- The ear pads are detachable for cleaning. Take them out from the earpieces and wipe them clean with a soft cloth dampened with neutral cleaning agent.

SPECIFICATIONS

Speaker	70 ϕ mm (3 in.) dynamic speaker
Impedance	8 Ω
Frequency response	20 to 20,000Hz
Sound pressure level	115dB/0.3V
Maximum input	500mW (each channel)
Cord length	2.5m (8.3feet), with 3-P plug
Weight	425g (15 oz), less cord

NOTE:

Specifications and the design subject to possible modification without notice due to improvements.

PIONEER ELECTRONIC CORPORATION

4-1, 1-Chome, Meguro, Meguro-ku, Tokyo 153, Japan

U.S. PIONEER ELECTRONICS CORPORATION

75 Oxford Drive, Moonachie, New Jersey 07074, U.S.A.

PIONEER ELECTRONIC (EUROPE) N.V.

Luithagensteenweg, "De Meermin", 2030 Antwerp, Belgium.

PIONEER ELECTRONICS AUSTRALIA PTY. LTD.

178-184 Boundary Road, Braeside, Victoria 3195, Australia.

Printed in Japan

<SRB-070-A>