


SX-1500TD

THE SOUND WELL 1425 GASKET, EUGENE, OREGON 97401 (503) 342-7071


S1 INPUT SELECTOR (1) AM (4) PHONO 1 (CERAMIC) (2) FM (5) PHONO 2 (3) F.M. AUTO (6) AUX

S2 MODE SELECTOR (1) STEREO REV (2) STEREO NORM (3) MONO L (4) MONO R (5) MONO L+R (6) SPEAKER A+B (7) SPEAKER A+C (8) PRE. & MAIN SELECTOR (1) SEPARATED (2) INTERCOUPLED


S3 OUTPUT SELECTOR (1) POWER OFF (2) SPEAKER A (3) SPEAKER OFF (4) SPEAKER B (5) SPEAKER C (6) SPEAKER A+B (7) SPEAKER A+C (8) PRE. & MAIN SELECTOR (1) SEPARATED (2) INTERCOUPLED




AM TUNER UNIT W14-008




FM FRONT END W11-028




FM IF UNIT W12-025




MUTING UNIT W18-026



FM MPX UNIT W13-024



PUSH SWITCH UNIT W15-081



SX-1500TD

- S₁ INPUT SELECTOR
 (1) AM (2) FM (3) FM AUTO (4) PHONO 1 (CERAMIC) (5) PHONO 2 (6) AUX
- S₂ MODE SELECTOR
 (1) STEREO REV (2) STEREO NORM (3) MONO L (4) MONO R (5) MONO L+R
- S₃ OUTPUT SELECTOR
 (1) POWER OFF (2) SPEAKER A (3) SPEAKER OFF (4) SPEAKER B (5) SPEAKER C (6) SPEAKER A+B (7) SPEAKER A+C (8) PRE. & MAIN SELECTOR (9) SEPARATED (10) INTERCOUPLED

