



- NOTES
- + 1 S<sub>1</sub>, S<sub>2</sub> ..... REC - PB SELECTOR SW (PB. POSITION)
  - + 2 S<sub>3</sub> ..... POWER SW
  - + 3 S<sub>4</sub> ..... SENSING MICRO SW
  - + 4 S<sub>5</sub> ..... PAUSE MICRO SW
  - + 5 VR<sub>1</sub>, VR<sub>6</sub> ..... P.B - EQUALIZER ADJ
  - VR<sub>2</sub>, VR<sub>7</sub> ..... P.B - LEVEL
  - VR<sub>3</sub>, VR<sub>8</sub> ..... REC - LEVEL
  - VR<sub>4</sub>, VR<sub>9</sub> ..... VU - LEVEL ADJ
  - VR<sub>5</sub>, VR<sub>10</sub> ..... REC - LEVEL ADJ
  - VR<sub>11</sub> ..... L(ch) BIAS ADJ
  - VR<sub>12</sub> ..... R(ch) BIAS ADJ

FUSE	
240V	0.5A
220V	
190V	
177V	
110V	1A