



NOTES

- |     |   |     |                      |
|-----|---|-----|----------------------|
| S1  | FWD - REV SELECTOR SW (FWD POSITION)        | VR1 | FWD - EQUALIZER ADJ  |
| S2  | REC - P.B. SW (P.B. POSITION)               | VR2 | REV - EQUALIZER ADJ  |
| S3  | EQUALIZER SELECTOR SW (EQ POSITION)         | VR3 | FWD - P.B. LEVEL ADJ |
| S4  | REC. MODE SW (ST. POSITION)                 | VR4 | REV - P.B. LEVEL ADJ |
| S5  | MUTING SW (PLAY POSITION)                   | VR5 | VU LEVEL ADJ         |
| S7  | CONTACT POINT OFF SW (PLAY / STOP POSITION) | VR6 | REC. LEVEL ADJ       |
| S8  | PRE SET SW                                  | VR7 | Lch. BIAS ADJ        |
| S9  | PLUNGER SW                                  | VR8 | Rch. BIAS ADJ        |
| S10 | MOTOR SW                                    | VR9 | DH. DUMMY ADJ        |
| S11 | SHUT OFF SW                                 |     |                      |
| S12 | POWER SW                                    |     |                      |
| S6  | OSC SW                                      |     |                      |
| RL1 | FWD - REV SELECTOR SW                       |     |                      |